

FIG. 1




FIG. 2





FIG. 3








FIG. 7








FIG. 10




FIG. 11

		П			,			1
Table 3	In tile 1204			u = load(uAddr)				
	Between tiles 1202 and 1204		uAddr transfers from 1202 to 1204		u transfers from 1204 to 1202			
	In tile 1202	uAddr = a + 4	wAddr = b + 8	r=a+b	s=5+c	x=u+r	s + w = y	Z=S+r
	Between tiles 1202 and 1206			wAddr transfers from 1202 to 1206		w transfers from 1206 to 1202		
	In tile 1206				w = load(wAddr)			
	Time	-	2	ო	4	2	9	7

FIG. 13

Table 4	In tile 1208				u = load(uAddr)			
	Between tiles 1202 and 1208		uAddr transfers from 1202 to 1204	uAddr transfers from 1204 to 1208		u transfers from 1208 to 1204	u transfers from 1204 to 1202	
	In tile 1202	uAddr = a + 4	wAddr = b + 8	r=a+b	s=5+c	Z = S + L	y = w + s	1+n=x
	Between tiles 1202 and 1206			wAddr transfers from 1202 to 1206		w transfers from 1206 to 1202		
	In tile 1206				w = load(wAddr)			
	Time	-	2	က	4	2	9	2

FIG 14

		·				·	,	
	In tile 1204				u = load(uAddr)			
	Between tiles 1202 and 1204			uAddr transfers from 1202 to 1204		u transfers from 1204 to 1202		
Table 5	In tile 1202	wAddr = b + 8	uAddr = a + 4	r=a+b	s=5+c	Z=S+L	x=u+r	s + w = y
	Between tiles 1202 and 1210		wAddr transfers from 1202 to 1206	wAddr transfers from 1206 to 1210		w transfers from 1210 to 1206	w transfers from 1206 to 1202	
	In tile 1210				w = load(wAddr)			
	Time	_	2	ო	4	c)	ဖ	7

FIG. 15